NITECOR

Features

- Utilizes CREE XM-L2 (U2) LED
- · Maximum output of 900 lumens
- Boasts a peak beam intensity of 9000 cd and a throw distance of up to 190 meters
- Dual-switch design ensures unprecedented ease of use
 Secondary red LED provides constant / flashing illumination
- Indicates battery voltage with a red flashing LED (accurate to 0.1V)
- · High efficiency constant current circuit enables maximum runtime of 10 hours
- A micro-textured reflector offers wide angle lighting
- Direct access to ultra-low and turbo output
- Reverse polarity protection prevents damage from an incorrectly inserted battery
- Detachable two-way anti-rolling clip
- Toughened ultra-clear mineral glass with anti-reflective coating
- Constructed from aero grade aluminum alloy
- HAIII military grade hard-anodized
- Waterproof in accordance with IPX-8 (2 meters submersible)
- · Impact resistant to 1.5 meters
- · Tail stand capability

Dimensions

Accessories

Length: 3.62" (92mm) Head diameter: 1" (25.4mm) Tail diameter: 0.79" (20mm)

Weight: 1.87oz (53 gram) (without battery)

Quality holster, clip, lanyard, spare o ring

Battery Options

	TYPE	Nominal voltage	Compatible
Primary AA battery	AA	1.5V	Y (Recommended)
Rechargeable AA battery	AA	1.2V	Y (Recommended)
Primary AA Lithium battery	L91	1.5V	Y
Primary LiFePO4 battery	14500	3.2V	Y
Rechargeable Li-ion battery	14500	3.7V	Y
IMR14500 Rechargeable Li-ion battery	IMR14500	3.7V	Y

* To ensure the best user experience performance-wise, it is recommended to use Nitecore

Output & Runtime

FL1 STANDARD	TURBO	HIGH	MID	LOW	LOWER	
IMR14500	900 LUMENS	300 LUMENS	160 LUMENS	70 LUMENS	1 LUMEN	
IMR.	30min	45min	1h30min	2h30min	12h	
A 1/7/	160 LUMENS	90 LUMENS	40 LUMENS	17 LUMENS	1 LUMEN	
Ò	45min	2h15min	2h45min	3h45min	10h	
M	190m (Beam Distance)					
	9000cd (Peak Beam Intensity)					
V	1.5m (Impact Resistant)					
M	IPX-8, 2m (Waterproof AND Submersible)					

NOTICE:

The stated data has been measured in accordance with the international flashlight testing standards ANSI/NEMA FL1, using 1 x high quality IMR 14500 battery (3.7V, 650mAh) or 1 x high quality AA battery (1.2V. 2500mAh) under laboratory conditions. The data may vary in real-world use due to different battery usage or environmental conditions

Operating Instructions Battery installation

Insert 1 x AA battery or 1 x IMR 14500 battery as illustrated NOTE: After loading the battery, the secondary red LED will flash to indicate battery voltage. Please refer to the "Power Tips" section of this manual for details.

WARNING:

- 1. Please stop using and remove a depleted IMR14500 battery to avoid potential battery damage.

 2. Ensure the battery is inserted with the positive (+) end
- pointing towards the head. The EA11 will not be operational with an incorrectly inserted battery.

On / Off Operation

To switch ON: Press the ON/OFF button once

To switch OFF: Press the ON/OFF button once again to switch the light off and enter standby mode

Standby Mode

With the light switched on, press and hold the ON/OFF button for more than one second to switch the light off and activate the secondary red LED to flash once every three seconds, thus helping the user locate the EA11 in dark conditions. When using an IMR 14500 battery, the EA11 will operate for up to 4 consecutive days with the red LED on, or remain on standby for more than 77 days with the red LED off.

Brightness Levels

With the EA11 switched on, press the MODE button repeatedly to cycle through the following brightness levels: ultra-low, low, medium, high and turbo. Once a brightness level is selected it will be saved and resumed when the EA11 is reactivated.

Direct Access to Ultra-low/Turbo Output

With the light switched off, press and hold the ON/OFF button for more than one second to

EA11 User Manual

access ultra-low mode (1 lumen).

With the light switched off, press and hold the MODE button for more than one second to access turbo mode (900 lumens).

NOTE: When in turbo mode, the EA11 will adjust output luminance automatically within 3 minutes of use to prevent overheating and extend battery longevity.

Red Light / Signal Light Mode

With the light switched off, press the MODE button 🛮 to enter red light mode. In this mode, the

secondary red LED will illuminate steadily.

When in red light mode, press and hold the MODE button for more than one second to enter signal light mode. In this mode, the secondary red LED will flash to serve as a signal light. Simply press any button to exit the red light /signal light mode.

Special modes (Strobe/Location/SOS)

With the light switched on, press and hold the MODE button from from one second to enter strobe mode. When in strobe mode, press and hold the MODE button from from one second again to cycle through Location Beacon, SOS and Strobe modes. To exit, simply press the MODE button ■ to resume the last used brightness level, or press the ON/OFF button o to switch the

Strobe Ready

With the light switched off, press the MODE button twice in quick succession to enter Strobe mode. To exit, simply press any button.

Lockout / Unlock

With the light switched on, press and hold the ON/OFF button and the MODE button simultaneously for over one second to switch the light off and enter lockout mode. In lockout mode, the EA11 conserves battery power for over 77 days; the two buttons on EA11 will not work, thus preventing accidental activation of the light. To exit lockout mode, simply press and hold the ON/OFF button and the MODE button simultaneously for over one second again. NOTE:

- 1. Upon entering lockout mode, the secondary red LED will flash to indicate battery voltage. Please
- refer to the "Power Tips" section for more details.

 2. When the EA11 is kept in a backpack or left unused for extended periods, Nitecore recommends the tailcap is loosened or the battery is removed to cut off the power entirely, thus preventing accidental activation of the flashlight or battery leakage.

Power Tips

After battery installation or lockout mode activation, the secondary red LED will flash to indicate battery voltage (accurate to 0.1V). For example, when battery voltage is at 1.3V, the red LED will flash once, followed by a one second pause and another 3 flashes. Different voltages represent the corresponding remaining battery power levels:

IMR 14500: AA:	Low Power Full P			ull Power
	3.5V	3.7V	3.9V	4.2V
	Low Power		Full Power	
	1.1V	1.2V	1.3V	1.4V

Changing / Charging Batteries

Batteries should be replaced or recharged when output appears to be dim or the flashlight becomes unresponsive.

Maintenance

Every 6 months, threads should be wiped with a clean cloth followed by a thin coating of silicon-based lubricant.

Warranty Service

All NITECORE® products are warranted for quality. Any defective / malfunctioning NITECORE® product can be repaired free of charge for a period of 60 months (5 years) from the date of purchase. Beyond 60 months (5 years), a limited warranty applies, covering the cost of labor and maintenance, but not the cost of accessories or replacement parts.

The warranty is nullified in all of the following situations:

- 1. The product(s) is/are broken down, reconstructed and/or modified by unauthorized parties
- The product(s) is/are damaged through improper use.
- 3. The product(s) is/are damaged by leakage of batteries

For the latest information on NITECORE® products and services, please contact a local NITECORE® distributor or send an email to service@nitecore.com

*All images, text and statements specified herein this user manual are for reference purpose only. Should any discrepancy occurs between this manual and information specified on www.nitecore.com, information on our official website shall prevail. Sysmax Industry Co., Ltd. reserves the rights to interpret and amend the content of this document at any time without prior notice.



SYSMAX Industry Co., Ltd. +86-20-83862000 TEL: FAX: E-mail:

+86-20-83882723 info@nitecore.com www.nitecore.com Web:





Address: Rm1401-03, Glorious Tower, 850 East Dongfeng Road, Guangzhou, China 510600